

# Ative o seu pacote myPOS



## Antes de iniciar a ativação, é necessário:

- O seu dispositivo myPOS ligado à Internet através de Bluetooth, Wi-Fi ou GPRS
- Browser da Internet para aceder a mypos.com
- Telemóvel (com capacidade para receber SMS)

## Como começar

O cartão de dados myPOS é totalmente GRATUITO para si e vamos fornecer-lhe um cartão para cada dos seus terminais myPOS. Nós garantimos a sua conectividade!

1. Vá para mypos.com e inicie sessão na sua conta myPOS.
2. Vá para o menu **Dispositivos** → **Ative o seu dispositivo**.  
  
Especifique as definições do seu dispositivo e o código de ativação vai ser apresentado na sua conta myPOS.
3. Depois de introduzir o código de ativação gerado, o dispositivo está pronto a ser utilizado. Clique em "A minha ativação está preparada" e já está!
4. Opcional - Ative o seu cartão-de-visitas pré-pago myPOS gratuito e tenha acesso imediato ao seu dinheiro

## Ativação bem-sucedida

Parabéns! O seu terminal myPOS está ativado e pronto a ser utilizado. Pode aceder à sua conta de dinheiro eletrónico em [mypos.com](https://mypos.com) ou através da

The image shows a sequence of three screenshots from the myPOS website and device interface, numbered 1, 2, and 3.   
Screenshot 1: The myPOS website homepage. It features a navigation bar with 'INDUSTRIES', 'PRODUCTS', 'PARTNERS', 'DEVELOPERS', 'ABOUT', and 'SHOP'. A 'Login' button is in the top right. The main content area includes a 'United Kingdom' dropdown menu, a 'Join myPOS now and start accepting payments from all your sales channels in one single platform.' message, and a list of benefits: 'No set up or monthly and annual fees', 'Rock-solid security and fraud protection', 'Instant worldwide money transfers', and 'Wide range of value-added services'. A 'CREATE ACCOUNT' button is at the bottom.   
Screenshot 2: The 'Activate Device' page. It has three steps: 'STEP 1 ENTER DEVICE SETTINGS', 'STEP 2 ENTER OUTLET SETTINGS', and 'STEP 3 REVIEW AND CONFIRM'. The first step is active. It contains fields for 'Enter device identifier \*' (with radio buttons for 'Serial Number' and 'Box barcode'), 'Enter device custom name', 'Select your device's currency \*', and 'Choose settlement account \*'. A 'Back' button and a 'Continue' button are at the bottom.   
Screenshot 3: The device activation screen. It shows a 'DEVICE ACTIVATION' window with 'ENTER ACTIVATION CODE' and a text input field. Below it are '(X) CANCEL' and '(O) CONFIRM' buttons. A 'Software update' dialog box is open, showing 'Checking for update...' with a progress indicator. Another 'Software update' dialog box shows 'SUCCESSFUL UPDATE Press any key to shutdown the device and then switch it on again.'

aplicação myPOS, disponível para Android e iOS. Para obter mais informações ou assistência, visite: [mypos.com](https://mypos.com)